




iRobot Roomba 655 Pet Series Side Brush and Back Panel Removal

How to remove the side brush and back panel of your Roomba

Written By: Matt Davis



INTRODUCTION



You will be removing the yellow side brush and the back panel of your Roomba in order to gain access to other components of your device.



TOOLS:


- [Phillips #2 Screwdriver](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Removing the Side Brush



- Flip the device over onto its back
 - Unscrew the single screw that connects the side brush to brush motor using the Phillips head #2 screwdriver
- i** This screw does not come out of the yellow side brush*

Step 2 — Removing the Back Panel



- Remove the four Phillips #1 screws on the back panel.
- Pop off the back plate once the screws are loose by gently prying away from the body
- ⓘ *The screws don't come completely out of the panel, but it will still come apart once unscrewed.*

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-19 01:05:42 PM.